

Bulletin:

Removal: Rear Passenger Bench Seat

8/28/2015



NOTICE:

The specifications, descriptions, information, and recommendations contained in this bulletin are believed to be accurate as of August 28, 2015.

Upfitter Management Vans reserves the right to modify or append this document without prior notification.

This bulletin is not intended as a work instruction, but as a guideline for upfitters to provide technical information necessary to retrofit or modify Mercedes-Benz Sprinters & Freightliner Sprinters (906).

Prior to making any modification to or installing any equipment in or on a Mercedes-Benz Sprinter & Freightliner Sprinter, please consult with Upfitter Management Vans for additional and updated information, and read the Body & Equipment Guidelines for Sprinter Model Series 906.

<u>Upfitter Management Vans Contacts</u>:

For information or upfitter inquiries please submit a request via our website: www.upfitterportal.com

How to disengage the rear 4 passenger bench seat latching lever







- To remove the rear seat row in a Sprinter passenger van is similar to the 2 front rows.
- ➤ Locate the two holes in the latching lever and insert a 90° bend needle nose pliers.
- Rotate pliers towards you. The latching lever will disengage.